





Overview

StarCam Mini PC Cam is a PC Camera using USB interface. Find the following items when unpacking:

- 1. StarCam 370i Web Camera
- 2. Software Pack CD
- 3. Quick Guide

Syst em Requi rement

To install StarCam, your computer system needs to meet the following requirements:

- Intel Pentium[®]4/III/II/Celeron [™], AMD[®]K6/Athlon [®]or compatible with USB connector
- 2. Operation System Support: Windows XP/2000/Me/98
- 3. 64MB of system memory
- 4. VGA support, minimum 640 x480 resolution
- 5. Installation software requires CD-ROM drive
- An optional mode m or a LAN card may be required for conference call
- 7. Hard disk with 50MB free space or above

Speci fication

Camera Lens	1/4 CMOS sensor 5G Glass Lens
Pixel	VGA Format 640x480
Resolution	640x480, 352x288, 320x240, 176x144, 160x120
Frame per secretary.	15fbs@640x480 and 30fbs @ 352x288
Capture Resolution	Up to 640x480 (iteration 1280x960)
FocusDistance	3cm ~ infinity
Lens Wide Angle	56 degree diagonal
Brightness	Auto
Exposed Control	Auto
Image Format	RGB24
Power Consumption	Full Run: 2w typical
Operation System	Windows 98/2000/Me/XP
I/O Interface	USB 1.1 Full Speed
USB Microphone	-45DB
LED Light	3 high bright white LED light
Infra red Light	0~2m high power

Installation

To install the driver of MSI StarCam, follow the instructions below::

- 1. Turn on the computer.
- Insert the provided driver disk into CD-ROM, and the auto run Setup program should be activated.
- Click Install MSI StarCam 370i Driver, and then click Next to continue.
- Follow the on-screen instructions to continue the installation.
- Click Finish to complete the installation and restart the system.
- 6. Connec t the StarCam to the USB port.
- Once the StarCam is connected to the computer, the system will detect the new USB device and configure the device. Automatically.



 To install the MSI My Guard[™] program, simply click the Install MSI My Guard, and follow the on-screen instructions to continue the installation.

SUCONEL

Cra 53 # 50-51 Locales 207-208 Pbx: (4)512 78 30 Fax: (4)512 75 94 e-mail: suconel@une.net.co www.suconel.com



- Capture 1.3 mega pixel photo picture
- Click & Snap Snapshot Button
- Bright & Light 3 White Light LEDs
- Plug & Talk Built-in USB Microphone
- Focus & Snap Adjustable Lens











3

Basic Usage

 \mathbf{T}

2

Adjusting the Picture Parameter

This StarCam Mini PC Cam allows users to adjust the picture parameters in accordance with personal choice.

To do this, follow the steps below:

- 1. Select [Start / All Programs / MSI StarCam 370i / AMCap] to activate the AMCAP (video camera window and check if StarCam works properly.
- 2. If there no image shown on the AMCAP window, please select [Option/ Preview] on the toolbar of AMCAP window.
- 3. To adjust video options, please select [Option/Video Capture Filter] to enter the Properties window.
- 4. Once the configuration is set, click Apply to see the result, or click **OK** to confirm the configuration and return to the AMCAP window.
- 5. If you are in the low illumination condition. you can select Low Light to improve the quality of image.
- 6. If you would like to make special effect on the image in Black-White color, please select the mode of Black-White.



- 7. Select [Option/Video Capture Pin] to enter the sub window.
 - Set Frame Rate: the default setting is 15fbs, set to 30fbs to smoothen the video capturing procedure.
 - Color: Available selections are RGB24 and 1420.
 - Image Size: Available selections are 160x120, 176x144, 320x240, 352x288, 640x480.

Life Recording


To do Life Recording, follow the steps below:

- 1. Select [File / Set Capture File] to setup a recording file (.avi) and then click OK b start recording.
- 2. To enable the audio function while recording, please select [Capture / Capture Audio]. Note that the Master Stream function can be ignored.
- 3. To adjust the amount of images be captured per second, please select [Capture / Set Frame Rate] and then enter a
- 4. To set up the recording ending timer, please select [Capture / Set Time Limit] and then enter a desired number of second. Once the recording timer arrives the time that is set, the recording will stop automatically.
- 5. To stop recording during the recording is on going manually, simply click the Esc icon,
- 6. To review the recording file, simply click on the recorded AVI

Image Capturing

To do Life Recording, follow the steps below:

- 1. Select [Start / All Programs / MSI StarCam 370i / AMCap] to activate the AMCAP (video camera window and check if StarCam works properly.
- 2. If there no image shown on the AMCAP window, please select [Option/ Preview] on the toolbar of AMCAP window.
- 3. Press "SnapShot" button to capture the instant live picture.



- 4. The save the captured image, select [File / Save as] to save the image to a desired location. and then close the image capturing window.
- 5. To capture another image, repeat the step 3 and 4.
- 6. If you need the image be captured in the diverse resolution, please select [Option/Video Capture Filter] to enter the Properties window, and the use the VGA snapsize slider to select the proper snap image size. The available selections
 - VGA: 640x480
 - SVGA: 800x600
 - XGA: 1024x768
 - SXGA: 1280x1024

Using Microphone

To microphone function, follow the steps below:

- 1. Select [Start / Control Pannel / Sounds and Audio Devices] to enter Sounds and Audio Devices Properties window. In this window, select the **Audio** tag, and then select USB Camera in the Sound recording drop menu.
- 2. Select [Start/All Programs / Accessories / Entertainment / Sound Recorder] to start recording the sound through the connected microphone.

MSI Special Feature

Infrared Light

StarCam equips with the Infrared Light function which allows users to see a clear image through StarCam in a darkroom.

To use Infrared Light function, please select [Option/Video Capture Filter] to enter the Properties window. In this window. you will find three options, Close, Open and Auto, under Aux LED mode to control the Infrared Light function.

Cra 53 # 50-51 Locales 207-208 Pbx: (4)512 78 30 Fax: (4)512 75 94 e-mail: suconel@une.net.co www.suconel.com

